# **USER GUIDE**



## LE-S102 Turbostrobe ODYSSEY

Thank you for choosing Odyssey Lighting. This lighting effect features a preinstalled lamp and is ready to be used.

### IMPORTANT!

Please read this User Guide before attempting to operate unit.

#### **OPERATING INSTRUCTIONS**

This unit is ready to be used. To ensure the longest possile lamp life, please follow the Duty Cycle. Place on a flat surface or mount upside down.

#### CAUTION

Effect will get extremely hot. Please use a 10 min on & 10 min off **Duty Cycle** for best operation. After unit has been used, give unit enough time to cool down before handling it. IMPORTANT! Never open effect when in use, always disconnect cord from voltage before handling or moving the unit.

#### **IMPORTANT!**


Never open the unit when in use. Always disconnect the power cord from the power source when replacing lamp or servicing the unit. Always replace fuse and lamp with the exact same type.

#### LAMP REPLACEMENT

Remove clear lens. Gently remove the old lamp, Then, using a clean cloth or glove, carefully insert the new lamp(s) into the black plastic socket(s). NEVER TOUCH A NEW LAMP WITH YOUR BARE HANDS or FINGERS (oil and dirt on your skin will damage the bulb).

#### TROUBLESHOOTING

1. If the effect does not turn on	a) try plugging into an outlet you know is working. b) check fuse & make sure it is not blown



Specifications		
Beam Spread:	Wide	
Lenses:	N/A	
Beam:	1	
Bulb:	1	
Lamp:	70W	
Color:	White	
Sound Active:	N	
Fuse:	1 Amp	
Power:	120V	
Duty Cycle:	10 min.	
Warranty:	90 days	
Width:	9"	
Height:	10"	
Depth:	11"	
Weight:	3 lbs.	

For service contact your local authorized ODYSSEY dealer or call 626.334.0800